

Installation Instructions for SBRP22 Pre-assembled Cartridge for Aprilaire / Space-Gard # 201



1. Remove access panel door of the air cleaner.



2. Remove the plastic inner housing from the main air cleaner housing.



3. Lay the housing on its side, open the two short sides, and lay them flat.



4. Remove the existing filter and pleat spacers. Do not remove the pink seals.



5. Lay the two long sides flat. Make sure to snap the flaps on the long sides shut.



6. Place the SBRP22 in the housing with the metal mesh side up. Bring the four sides up and snap together. It will be a **snug** fit.



7. Re-install assembly into the main air cleaner housing. Replace the access door.

Filter Solution USA
Toll Free 866-385-2098
info@filtersolution.com


FILTERSOLUTION.com
AIR & WATER FILTER PRODUCTS

©2004 Filter Solution USA, Inc. All rights reserved.